


# Centration Chart KM Explorer HD Ultimate



## HOW TO MEASURE FRAME WRAP / ZTILT

Place the frame, top side down, over the highlighted gray frame image. Ensure the frame is placed as it is shown in the picture. Record the angle of frame wrap from the extreme right side of where the lens ends, not where the frame ends.



## PLEASE NOTE:

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm




## DEFAULT PERSONALIZATION PARAMETERS

Wrap	Panto	Vertex
5°	12°	14 mm

## ENGRAVING INDEX

M = Material DC = Design Code ADD = Addition Power

Product	Design Code
KM Explorer HD Ultimate	ES
KM Explorer HD Ultimate Distance	ESd
KM Explorer HD Ultimate Intermediate	ESi
KM Explorer HD Ultimate Near	ESn



Endless Steady Progressive lenses are open format designs, compatible with any spherical lens blank. Drop = 4 mm. Recommended MFHs are 14, 15, 16, 17, and 18 mm (infinitesimal steps). Contact your laboratory for more information.